

# HOUSE ONE

## DIY HANGING PLANTER

WWW.HOUSE.ONE - BY JENN LARGESSE



A wall-mounted planter adds the perfect pop of greenery and style to any space. For this project, all you need is a small planter pot, a 1 x 2 board, and Original Gorilla Glue.

*This project is sponsored by Gorilla Glue. All opinions are our own.*

### CUT LIST

See diagram on page 3  
for miter instructions  
1 x 2 Sides – 2 @ 11 3/4"  
1 x 2 Sides – 1 @ 9 41/64"  
Crosspiece – 1 @ 4 3/64"

### MATERIALS

(1) 1 x 2 x 6 Board  
(1) 4-inch Pot  
Original Gorilla Glue  
Gorilla Tape  
Latex Gloves  
Cloth or Rag  
Sanding Sponge

### TOOLS

Miter Saw  
Hand Clamps

### STEPS

#### STEP 1 – MARK THE CUTS

Using the cut list above, mark the cut lines on the 1 x 2 board.

## **STEP 2 – CUT THE PIECES**

Position the angle of the cut on the miter saw. Cut along the first line. Reposition the miter saw, and then cut the second line. Repeat to cut the remaining pieces.

## **STEP 3 – LAYOUT THE PIECES**

Position the pieces so that they create a diamond shape. Place the planter support piece in the center of the diamond, just below the centerline.

## **STEP 4 – DAMPEN ONE SIDE OF THE FIRST CONNECTION**

Because Original Gorilla Glue is activated by moisture, first wet the end of the first board with a damp cloth.

## **STEP 5 – APPLY GLUE TO THE FIRST BOARD**

Apply a thin bead of glue to the edge of the first board.

## **STEP 6 – “CLAMP” THE BOARDS WITH TAPE**

Position the boards into place, and then wrap the joint with a small piece of Gorilla Tape to “clamp”, or hold the connection tightly in place. Repeat to secure the remaining 1 x 2 boards using a damp cloth, glue, and tape.

## **STEP 7 – ADD THE CROSSPIECE**

Dampen the inside edges of the diamond, just below the centerline. Apply glue to the ends of the crosspiece, and then position it in place. Clamp the joints with tape.

## **STEP 8 – MOUNT THE POT**

Wet the front of the crosspiece. Apply Original Gorilla Glue to the outside rim of the pot. Center the pot on the crosspiece, and use a hand clamp to hold it in place. Allow the glue to cure for 24 hours.

## **STEP 9 – SAND THE ASSEMBLY**

Remove the clamp and tape from the assembly. Sand the parts and any visible glue using a sanding sponge.

## **STEP 10 – INSTALL THE PLANTER**

Drive a screw through the planter and into the wall to hold it in place. As always, using a wall anchor or hitting a stud is recommended.

